

avenlur

Easel by Avenlur



Need Help?

CALL US AT 888.697.3931 / M-F 9AM - 5PM PT (12PM - -8PM ET)

OR EMAIL US AT INFO@AVENLUR.COM

V2

WARNING

Adult assembly required.

WARNING

CHOKING HAZARD:

Adult assembly required. Keep small assembly parts out of reach of children.

 Use under adult supervision.

OBSERVE ALL STATEMENTS AND WARNINGS TO REDUCE THE LIKELIHOOD OF SERIOUS OR FATAL INJURY.
SAVE THIS SHEET FOR FUTURE REFERENCE.

OPERATION INSTRUCTIONS

1. An adult should always supervise use of this product by children of all ages.
2. Instruct children not to attach items to the playground equipment that are not specifically designed for use with the equipment (examples: ropes, clothesline, pet leashes, cables and chain, etc) as they may cause a strangulation hazard or any other hazard.
3. Never allow children to use the equipment in a manner other than intended.

MAINTENANCE INSTRUCTIONS

1. Inspect the product periodically for loose or damaged components. **Tighten bolts if need.**
2. Check all connections and bolts for tightness at least twice monthly during the usage.
3. Check all coverings and bolts for sharp edges.

INSTALLATION INSTRUCTIONS

Please have an electrical drill available for assembly if possible.

If you have difficulty in installation, please contact us for help and get installation video for reference.

Please Ensure:


1. You are assembling with at least two people to ensure that all sides and parts are leveled.
2. You don't screw the parts in too hard or it will splinter the wood.
3. You follow the directions carefully.

CONTACT US BEFORE ASSEMBLY IF:


- You need assistance with assembly
- You need a replacement part due to a missing part or defective part

Call us at 888-697-3931 M-F 9AM-5PM PT


or email us at info@avenlur.com




① ×2 29.5in




③ ×1 19.5in




⑤ ×2 21.0in




⑥ ×4 29.5in




⑦ ×1 22.0in




⑧ ×4 19.0in




⑨ ×2 19.0in




M4x35
① ×8




M6x30
② ×2



M4x50
③ ×16



M6x40
④ ×12




M6x30
⑤ ×6




4mm
⑥ ×1




② ×2 29.5in




④ ×1 19.5in



⑩ ×1




⑪ ×1




⑫ ×1 21.5in


01-1




01-2




02-1




02-2



E	 M6×40	8
----------	---	---

03-1



A	 M4×35	8
----------	---	---

04-1

11

10

C×3

C×3

D

D

C

M6×30

6

D

M6×30

2

05-1

7

E

E

E

E


03-1

E

M6×40



4

CHANGING HEIGHT FROM TALL, to MEDIUM or SMALL: Remove all 8 **E** screws on the legs.




MEDIUM:

SMALL:



MEDIUM



SMALL

Note: Check all connections and bolts for tightness at least twice monthly during use. Do not use if screws are loose.

